






playmobil®



5528






1




2





3




4





5




6



7




8



1



2



3



D **A** **CH** **L** **B** Montage nur durch Erwachsene!

USA **GB** **CDN** **M** **IRL** Adult assembly only!

F **CDN** **B** **L** **CH** Le montage doit être réalisé par un adulte

E **MEX** ¡Solo se debe montar por adultos!

NL **B** Opbouw enkel door volwassenen!

I **CH** Assemblabile solo da adulti

P Só deve-se montar por adultos!

DK Skal monteres af en voksen!

N Må monteres av en voksen!

S **FIN** Får endast monteras av vuxen!

FIN Aikuisen on koottava tuote.

H Szülő felügyelet szükséges!

CZ Montovat smí jenom dospělí!

EST Monteerida tohivad ainult täiskasvanud!

LV Montāžu drīkst veikt tikai pieaugušie!

LT Montavimą gali atlikti tik suaugusieji!

SLO Izdelek lahko sestavijo le odrasle osebe!

SK Montáž len prostredníctvom dospelých osoby!

PL Montaż tylko przez osoby dorosłe!

TR **CY** Montaj yalnızca yetişkinler tarafından yapılmalı!

GR **CY** Η συναρμολόγηση πρέπει να γίνει οπωσδήποτε από κάποιον ενήλικο!

RO Montarea se efectuează doar de către adulți!

BG Монтажът следва да се извършва само от възрастни!!

CN 只能由成年人组装!